

# Canopy Head Rest Support Instructions

1. Attach Black Nylon clamp on vertical tube on the canopy.



2. Remove Headrest from scooter and insert headrest rod into holes in the 16mm support tube. If this hole is too small for the headrest, it may have to be drilled to a larger diameter to suit.



3. Slide 20mm tube over the 16mm tube and attach to the Nylon clamp.



4. Make sure canopy is setup up level and positioned correctly before inserting tec screws in pre drilled pilot holes in the 20mm tube.



5. Move the Nylon clamp up or down and apply a small amount of vertical pressure on it before tightening up the clamp.

