



Slide Tow Bar Clamp onto "L" piece with the clamping tab facing the scooter.

Insert "L" piece into scooter accessory outlet and clamp "L" piece into place.

Slide Tow Bar Clamp over the Accessory outlet and tighten the 8mm bolt.